


ROCCAT
ELO 7.1 USB





QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE

PACKAGE CONTAINS CONTENU DE LA BOÎTE

Removable Microphone

Microphone amovible



Elo 7.1 USB Gaming Headset

Casque de jeu Elo 7.1 USB

HEADSET CONTROLS COMMANDES SUR CASQUE

Volume Control


Réglage du volume

Variable Mic Monitoring


Réglage du retour microphone

Mic Mute On/Off

Interrupteur microphone muet



PC/MAC® SETUP | CONFIGURATION POUR PC/MAC®



EN

1. Plug the Elo 7.1 USB in your PC
2. Right click the speaker icon in your toolbar and select "Open Sound Settings"
3. Select "Elo 7.1 USB" from the "Choose Your Output Device" drop-down menu
4. Open the driver software to customize your settings

ES

1. Enchufa el Elo 7.1 USB en tu PC
2. Haz clic con el botón derecho en el icono de altavoz de tu barra de herramientas y selecciona "Abrir configuración de sonido"
3. En el menú desplegable "Elige el dispositivo de salida", selecciona "Elo 7.1 USB"
4. Abre el software de controlador para personalizar la configuración

IT

1. Collega le Elo 7.1 USB al tuo PC
2. Fai clic con il pulsante destro del mouse sull'icona dell'altoparlante nella barra degli strumenti e seleziona ""Apri impostazioni audio""
3. Seleziona ""Elo 7.1 USB"" dal menu a discesa ""Scegli dispositivo di output""
4. Avvia il software dei driver per personalizzare le tue impostazioni

DE

1. Schließe das ELO 7.1 USB an den PC an
2. Klicke mit rechts auf das Lautsprechersymbol in deiner Symbolleiste und öffne die Soundeinstellungen
3. Wähle bei „Ausgabegerät auswählen“ im Dropdownmenü das ELO 7.1 USB aus
4. Öffne die Treiber-Software, um deine Einstellungen anzupassen

FR

1. Branchez l'Elo 7.1 USB sur votre PC
2. Faites un clic droit sur l'icône en forme de haut-parleur dans votre barre d'outils et cliquez sur Ouvrir les paramètres de son
3. Sélectionnez l'Elo 7.1 USB dans le menu déroulant Choisir votre périphérique de sortie
4. Ouvrez le logiciel de pilotes pour personnaliser vos options



SE

1. Anslut Elo 7.1 USB till din dator
2. Högerklicka på högtalarikonen i verktygsfältet och välj Öppna Ljudinställningar
3. Välj ""Elo 7.1 USB"" från menyn Välj utdataenhet
4. Öppna drivrutinsprogramvaran för att anpassa dina inställningar

To access the rating label: Pour accéder à l'étiquette :

1. Remove the left ear pad by pulling the ear pad straight up using your thumb.
1. Retirez le coussinet gauche en le tirant vers le haut à l'aide de votre pouce.
2. Once you've released the cloth from the lip on top, pull the ear pad straight back and it should slip right off.
2. Une fois le haut du tissu dégagé, tirez le coussinet vers vous pour le retirer facilement.

To replace the ear pad, follow the same process in reverse.
Pour remettre le coussinet en place, veuillez suivre la procédure inverse.



TECHNICAL FACTS

TECH SPECS

- Wired USB-A cable connection
- 20Hz – 20kHz speaker frequency response
- 50mm speakers with neodymium magnets
- Audio controls: master volume wheel, mic mute, mic monitor wheel
- Removable unidirectional microphone
- Leatherette headband with foam cushioning
- Over-ear design featuring memory foam

SYSTEM REQUIREMENTS

- Windows® 7, 8 and 10 (software support)
- USB 2.0 (or higher)
- Internet connection (for driver software)

Should you need assistance ...

Our support team is ready to help you with any technical questions.
Just send an e-mail to support@roccat.com or visit our website at:

WWW.ROCCAT.COM/SUPPORT

REGULATORY COMPLIANCE STATEMENTS FOR THE ELO 7.1 USB

FEDERAL COMMUNICATIONS COMMISSION (FCC) COMPLIANCE NOTICES

CLASS B INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15, Subpart B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product is compliant with the Consumer Product Safety Improvement Act of 2008, Public Law 110-314 (CPSIA)

CANADIAN ICES STATEMENTS

Canadian Department of Communications Radio Interference Regulations

This digital apparatus does not exceed the Class B limits for radio-noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique respecte les limites de bruits radioélectriques visant les appareils numériques de classe B prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada. Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

VOYETRA TURTLE BEACH, INC. | 44 SOUTH BROADWAY, 4TH FLOOR, WHITE PLAINS NY 10601, USA

© 2021 Voyetra Turtle Beach, Inc. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. Voyetra Turtle Beach, Inc shall not be made liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

EUROPEAN UNION AND EUROPEAN FAIR TRADE ASSOCIATION (EFTA) REGULATORY COMPLIANCE

Declaration of Conformity

Marking by this symbol:



indicates compliance with the Essential Requirements of the EMC Directive of the European Union (2014/30/EU). This equipment meets the following conformance standards:

Safety: EN 50332-2:2015, EN71-3:2013

Emissions: EN 55032:2015+AC:2016, EN55035:2017+AC:2019-11, AN/NZS CISPR32:2015

Immunity: EN55024:2010+A1:2015, AN/NZS CISPR24:2010+A1:2015

The products are licensed, as required, for additional country specific standards for the International Marketplace. Additional issued licenses available upon request.

Environmental: REACH 2006/1907/EC,
RoHS 2015/863 amending Annex II to Directive 2011/65/EU,
WEEE 2012/19/EU, Packaging 94/62/EC, Toys Safety Directive 2009/48/EC

Please visit the following URL for a complete copy of the Declaration of Conformity:

<http://www.turtlebeach.com/homologation>



This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.



Class B

この装置は、情報処理装置等電波障害自主規制協議会[VCCI]の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。



Turtle Beach Europe Ltd is obligated as a producer with a main activity of selling under The Producer Responsibility Obligations (Packaging Waste) Regulations 2007. To fulfil our obligation we are registered with Comply Direct and their Recycling Room. Here you will find advice and information on packaging waste management, recycling symbols and the waste hierarchy principles of reduce, reuse and recycle.

<https://www.complydirect.com/the-recycling-room/>

ID005

426-193-004-005



WWW.ROCCAT.COM