



SECURE & STABLE



DISTINCTIVE DESIGN

ROCCAT™ TALK® - SET BONUS



Products supporting the ROCCAT™ Talk® protocol can communicate with each other, advanced set bonus gaming advantages. For instance, you can program a keyboard key to change the DPI resolution on your mouse. Conversely, the mouse can also execute keyboard functions such as Easy-Shift[+]™.

CONGRATULATIONS!

The ROCCAT™ Isku – Illuminated Gaming Keyboard offers innovative features combined with intelligent technology and maximum ease of use. The feature-rich driver package offers, among other things, a host of unique customization options, including the ROCCAT™ Easy-Shift[+]™ function. The medium-height keys have a precise full keystroke pressure point – plus the three ROCCAT™ Thumbster keys give you additional flexibility.

Easy-Shift[+]™: 3 key duplication zones

ROCCAT™ Easy-Shift[+]™ technology has come to the keyboard and now allows multiple functions to be assigned to keys within the 3 Easy-Shift[+]™ Zones. The Easy Zone integrated within the WASD zone offers over 20 additional macro keys – all intuitive to use and easy to reach.

Macro Live! Recording

36 programmable macro keys offer maximum control. Access over 180 macros in a flash thanks to ultra-fast profile switching. Plus easily record sophisticated command sequences live, and assign them to a selectable key, using the dedicated Macro Live! Recording button.

Operability and Ease of Use

The ROCCAT™ Isku is the perfect companion for long gaming nights. The integrated, extra-large granular wrist rest with its special surface texture allows you to respond with maximum speed. Plus the 8 media keys, with over 25 assignable media, web and computer control functions, further boost ease of use.



SPECIFICATIONS

PACKAGE CONTAINS

- ROCCAT™ Isku – Illuminated Gaming Keyboard
- Quick-Installation Guide

SYSTEM REQUIREMENTS

- Windows® XP, Windows Vista® 32/64 bit, Windows® 7 32/64 bit, Windows® 8/Windows® 8 Pro
- Internet connection (for driver installation)
- USB 2.0 port

KEYBOARD SIZE

- 509mm x 247mm (width x length)
- Front height: 10mm / Back height: 32mm
- Back height adjustment: 42mm

TECH SPECS

- Illuminated keyboard with 123 keys
- Enhanced anti-ghosting capability
- 3 programmable ROCCAT™ Thumbster Keys (T1-T3)
- 5 programmable Macro Keys (M1-M5)
- 20 additional Macro Keys (Easy Zone)
- 5 Profile-Status LEDs
- 3 Status LEDs (Caps Lock, Easy-Shift[+]™, Num Lock)
- 1000Hz polling rate, 1ms response time
- 2m USB cable



QUICK-INSTALLATION GUIDE

IMPORTANT DOCUMENT


Should you need assistance ...

Our support team is ready to help with any technical questions. Just send an e-mail to support@roccat.org. Or visit our website at:

WWW.ROCCAT.ORG/SUPPORT



PLEASE USE YOUR PRODUCT'S SERIAL NUMBER (LOCATED ON THE BOTTOM LABEL) FOR REGISTRATION. SIGN IN AT: ROCCAT.ORG/REGISTER



ROCCAT GmbH

Otto von Bahrenpark, Paul-Dessau-Str. 3G, 22761 Hamburg, Germany

© 2014 ROCCAT GmbH. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. ROCCAT GmbH shall not be made liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

ROCCAT™ EASY-SHIFT[+]™

THE DUAL KEY ASSIGNMENT FUNCTION

EASY-SHIFT[+]™: ASSIGNING DUAL KEY FUNCTIONS

ROCCAT™ Easy-Shift[+]™ lets you assign two functions to dedicated keys (in blue) – so they can perform additional tasks. The Easy-Shift[+]™ key works just like the shift key on a keyboard: Press it while simultaneously holding down one of the dedicated Easy-Shift[+]™ keys to execute the second function.

Easy-Shift[+]™ makes it simple to double the number of key functions. And we put the Easy-Shift[+]™ keys in areas that are the quickest and easiest to reach. Ultimate ergonomics and maximum functionality finally coexist in harmony!

PRACTICAL MACRO CONTROLS

The Isku also comes with our award-winning ROCCAT™ Macro Manager. Use the Macro Manager to create short or complex command sequences for your applications and games. Just like the preconfigured ones supplied with the driver, these custom macros can be easily assigned to any one of the Isku's macro keys – and, of course, as a dual-assignment in combination with the Easy-Shift[+]™ key. Plus, all of the keyboard settings, including the key assignments, can be stored in any one of 5 game profiles and automatically loaded when a game is launched. If one profile is set as the 'Windows Profile', this is automatically loaded when you return to Windows®.

additional macro keys (M1-M5)

Easy Zone keys:
20 additional, easy-to-reach
macros & functions via
Easy-Shift[+]™

ROCCAT™ Thumbster
keys (T1-T3)

Easy-Shift[+]™ key:
Caps Lock, Macro keys
(M1-M5) and ROCCAT™ Thumbster
keys (T1-T3) can also be assigned
as the Easy-Shift[+]™ key.

Use the **Easy-Shift[+]™** key (assignable to Caps Lock, M1-M5 and T1-T3) to program 2nd level functions on all highlighted keys.

This means you virtually double your Macro keys – for easy access to up to 36 powerful functions.

EASY-SHIFT[+]™ EXAMPLES:

[+] = Easy-Shift[+]™ key

Easy-Shift[+]™ WoW:

[+] + 1 = Mount up	[+] + A = Use hearthstone
[+] + 2 = Dismount	[+] + S = Autorun
[+] + 3 = Pet attack	[+] + D = Hotbar slot #1
[+] + 4 = Pet passive	[+] + F = Hotbar slot #2
[+] + 5 = Pet follow	[+] + G = Start timer
[+] + Q = Yell chat	[+] + Z = Your macro #1
[+] + W = World map	[+] + X = Your macro #2
[+] + E = Trade chat	[+] + C = Your macro #3
[+] + R = Raid chat	[+] + V = Your macro #4
[+] + T = Party chat	[+] + B = Your macro #5

Easy-Shift[+]™ Multimedia:

[+] + M1 = Play or pause
[+] + M2 = Stop playback
[+] + M3 = Play the previous item
[+] + M4 = Play the next item
[+] + M5 = Rewind

Easy-Shift[+]™ Browser:


[+] + M1 = New tab
[+] + M2 = New window
[+] + M3 = Switch to previous tab
[+] + M4 = Switch to next tab
[+] + M5 = Switch to full screen & back

[+] + T1 = Volume up
[+] + T2 = Volume down
[+] + T3 = Mute volume


[+] + T1 = Page back
[+] + T2 = Page forward
[+] + T3 = Minimize window

HOW TO USE MACRO LIVE! RECORDING


1 START LIVE! RECORDING PRESS "M-REC"-BUTTON



2 ASSIGN A MACRO KEY EXAMPLE: M1




3 TYPE YOUR OWN MACRO EXAMPLE: "HELLO"



PLEASE NOTE:
THE DELAY WILL ALSO BE RECORDED
AFTER PRESSING THE "REC"-KEY.

4 STOP LIVE! RECORDING PRESS "M-REC"-BUTTON AGAIN



DE

ANLEITUNG

- Für einen ergonomischen Stand klappe die Füße an der Unterseite der Tastatur aus.
- Verbinde den USB-Stecker der ROCCAT™ Isku mit einer freien USB-Schnittstelle.
- Starte deinen Computer und stelle eine Verbindung mit dem Internet her.
- Gebe in die Adresszeile deines Webbrowsers die folgende URL ein „www.roccat.org/support“ und drücke Enter.
- Klicke in der linken Navigationsleiste auf den Punkt „ROCCAT Isku“. Lade dir auf der sich öffnenden Seite die neueste Treiber-Software herunter.
- Starte die Treiber-Installation und folge bitte den weiteren Anweisungen auf dem Bildschirm.

DK

INSTRUKTIONER

- Til ergonomisk opstilling klappes fødderne på tastaturets bund ud.
- Forbind ROCCAT™ Isku's USB-stik med et ledigt USB-interface.
- Start din computer og forbind den med Internettet.
- Indtast følgende URL i adresselinjen af din webbrowser „www.roccat.org/support“ og tryk så Enter.
- Klik i venstre navigationslinje på punkt „ROCCAT Isku“. Fra den åbnede side overfører du den nyeste driversoftware.
- Start driver-installationen og følg anvisningerne på billedskærmen.

EN

INSTRUCTIONS

- For a more ergonomic position, fold out the stands on the base of the keyboard.
- Plug the ROCCAT™ Isku's USB connector into any free USB port.
- Boot your computer and connect to the internet.
- Enter 'www.roccat.org/support' in your browser and hit the return key.
- In the navigation bar on the left, go to 'ROCCAT Isku'. Download the latest driver from the webpage that opens.
- Start the driver installation process and follow the on-screen instructions.

ES

INSTRUCCIONES

- Para un equilibrio más ergonómico, saca las patas que están debajo del teclado.
- Enchufa el conector USB del ROCCAT™ Isku a un puerto libre USB.
- Käynnistä tietokoneesi ja luo Internet-yhteys.
- Escribe en tu navegador Web la siguiente URL: www.roccat.org/support y pulsa Enter.
- En la barra izquierda de navegación haz clic en el punto "ROCCAT Isku". En la página que se abre a continuación descarga el software de controlador más actualizado.
- Inicio la instalación del controlador y sigue las instrucciones que aparecen en pantalla.

FI

OHJEET

- Käännä näppäimistön alla olevat jalat ulos ergonomista asentoa varten.
- Liitä ROCCAT™ Isku:n USB-pistoke vapaaseen USB-liitäntään.
- Käynnistä tietokoneesi ja luo Internet-yhteys.
- Kirjoita verkkoselaimesi osoiteriville seuraava URL-osoite „www.roccat.org/support“ ja paina Enter.
- Napsauta vasemmasta navigaatiopalkista kohtaa „ROCCAT Isku“. Lataa avautuvalla sivulla uusin ajuriohjelmisto.
- Käynnistä ajurin asennus ja noudata näytöllä näkyviä lisäohjeita.

FR

INSTRUCTIONS

- Déplie les pieds sur la face inférieure du clavier pour une plus grande ergonomie.
- Relie la fiche USB de la souris ROCCAT™ Isku à une prise USB libre.
- Uruchom komputer i nawiąż połączenie z Internetem.
- W wierszu adresowym przeglądarki wpisz adres URL « www.roccat.org/support » et appuie sur Enter.
- Clique dans le menu de navigation de gauche sur « ROCCAT Isku ». Télécharge la dernière version du pilote sur la page qui s'ouvre alors.
- Lance l'installation du pilote et suis les instructions qui s'affichent à l'écran.

PL

INSTRUKCJA

- Aby uzyskać pozycję ergonomiczną, rozłóż nóżki po spodniej stronie klawiatury.
- Podłącz wtyk USB ROCCAT™ Isku do wolnego złącza USB.
- Uruchom komputer i nawiąż połączenie z Internetem.
- W wierszu adresowym przeglądarki wpisz adres URL „www.roccat.org/support“ i naciśnij Enter.
- W lewym pasku nawigacji kliknij punkt „ROCCAT Isku“. Z nowo otwartej strony pobierz najnowsze sterowniki.
- Rozpocznij instalację sterowników i postępuj zgodnie z instrukcjami na ekranie.

PT

INSTRUÇÕES

- Para um apoio mais ergonómico, abre os pés de apoio na parte inferior do teclado.
- Liga a ficha USB do ROCCAT™ Isku a uma interface USB livre.
- Inicio o teu computador e estabelece uma ligação à internet.
- Introduz o seguinte URL "www.roccat.org/support" na barra de endereços do teu navegador de internet e pressiona Enter.
- Clica na barra de navegação à esquerda no ponto "ROCCAT™ Isku". Na página que abre, faz o download do mais recente software de driver.
- Inicio a instalação do driver e segue as instruções seguintes no monitor.

RU

ИНСТРУКЦИИ

- Для обеспечения эргономичного положения открой ножки на нижней стороне клавиатуры.
- Соедини USB-штекер ROCCAT™ Isku со свободным USB-портом.
- Запусти компьютер и выйди в интернет.
- Введи в адресной строке браузера адрес „www.roccat.org/support“ и нажми Enter.
- Нажми на левой навигационной панели пункт „ROCCAT Isku“. Загрузи с открывшейся страницы самые последние драйвера.
- Запусти установку драйвера и следуй дальнейшим указаниям на экране.

SE

INSTRUKTIONER

- Fäll ut fötterna under tangentbordet så att det står i en ergonomisk ställning.
- Sätt ROCCAT™ Isku USB-kontakt i en ledig USB-port.
- Starta datorn och koppla upp dig på Internet.
- Skriv in följande URL i adressfältet på din webbläsare: www.roccat.org/support. Tryck på Enter.
- Klicka på ROCCAT Isku i det vänstra navigationsfältet. Ladda ner den senaste programvaran med drivrutin på den sida som öppnas.
- Starta installationen av drivrutin och följ anvisningarna på skärmen.